



\triangle = CRITICAL DIM

* For 13/16" Door Thickness, 3/4" Panel Thickness